



Carlson Pet Products ***Top Dog***

Top of Stairs Gate Model 1330PW & 1335PW



CONTACT INFORMATION

For technical support call our customer care line: 952-435-1084
or email customerservice@carlsonpet.com

.....
Please retain information for future reference.

MADE IN CHINA

COPYRIGHT 2010 CARLSON PET PRODUCTS, INC.
14305 Southcross Drive, Burnsville, MN 55306

210mm

148mm

尺寸: 210mm X 148mm

印刷: 黑白印刷, 书本式装订

纸张: 80g A5纸

WARNING:

- To prevent serious injury or death, securely install gate and use according to manufacturer's instructions.
- This gate is to be used with pet's only.
- Never leave pet unattended.
- Use only with lock securely engaged.
- Always close gate behind you.
- Do not use if any components are missing or damaged.
- Check daily that the mounting hardware is securely anchored to the newel or wall.
- This product will not necessarily prevent all accidents.
- Proper supervision is required at all times.
- Adult assembly required.
- Keep small parts away from pets and children.

IMPORTANT! KEEP FOR FUTURE REFERENCE


MAINTENANCE:

1. Regularly check mounting hardware and all parts to ensure the gate is secure and in place.
2. Do not use gate if any components are damaged or missing.
3. Wipe surface with a damp cloth using a mild detergent and warm water.

TOP OF STAIRS GATE COMPONENTS :

1 of 7

- | | |
|---|---|
| A) Gate | B) Locking Latch |
| C) End Pin - 1 on each corner of Gate | D) Vertical Mounting Tube x 2 |
| E) Plastic Wall Spacer x 6 | F) Bubble level (Located on both Vertical Mounting Tubes) |
| G) Top Round Banister Adapter x 2 | H) Foot |
| I) Bottom Banister Post Adapter. x 2. | J) Bottom Corner Protectors x 8 |
| K) Velcro Straps attached with the buckle X 4 (not shown) | |
| L) Wall Screws 1.5" inch x 6 | M) Wall Screws 2.5" inch x 6 |
| N) Locking Tab x 4 (not shown) | |



Installation Options :

2 of 7

Option A1 Mounting to Wall **WITHOUT**
Baseboard [see page 3](#)

Option A2 Mounting to Wall **WITH**
Baseboard [see page 4](#)



Option B Mounting to Banister Post
[see page 5](#)



Attaching Your Gate
[see page 7](#)



Parts needed for wall side:


1. Part D: Vertical Mounting Tube x 1
2. Part L: Wall Screws 1.5" inch x 3

Attaching the Vertical Mounting Tube to the Wall.

Warning: When fastening the Vertical Mounting Tube to your wall MAKE SURE that you are fastening the screws into a stud in the wall, OR that you use the appropriate wall anchors. If you do not, the screws may pull out of your wall and the gate will become unsafe to use.


NO Baseboard Molding-

1. If you have no base board molding then all you will need to do is take the Vertical Mounting Tube (D), and place it up against the wall so it is level and straight. The bottom of the Vertical Mounting Tube MUST be resting on the floor. You will be able to tell if the Vertical Mounting Tube is level by looking at the bubble level on top of the Vertical Mounting Tube. If the bubble is in the middle of the circle then the tube is level. If not, adjust the Vertical Mounting Tube until the bubble is in the middle of the circle.



Bubble Level

2. Next, take the 3 Short Wall Screws, L, and fasten the Vertical Mounting Tube, D, to the wall through the 3 holes in the tube.



3. Repeat steps 1-2 if installing to another wall on the opposite side. If the opposite side is a wall with a Baseboard, see page 4. If the opposite side is a Banister Post, see page 5.
4. Once the Vertical Mounting Tubes are securely mounted on both sides of the opening, see page 6.

Option A2 Mounting to Wall WITH Baseboard

4 of 7

Parts needed for wall side:

1. Part D: Vertical Mounting Tube x1
2. Part E: Plastic Wall Spacers x3
3. Part M: Wall Screws x 3 (2.5" Long)

Attaching the Vertical Mounting Tube using the Wall Spacers as shown below:

Warning: When fastening the Vertical Mounting Tube to your wall MAKE SURE that you are fastening the screws into a stud in the wall, OR that you use the appropriate wall anchors. If you do not, the screws may pull out of your wall and the gate will become unsafe to use.

1. Begin by taking 1 of the Plastic Wall Spacers and placing it against the wall just above the baseboard where you want the gate to be.

2. Next, take 1 of the Vertical Mounting Tubes and place it over top of the Plastic Wall Spacer. Make sure the bottom of the Vertical Mounting Tube is resting on the floor.



3. Next, align the bottom screw hole in the Vertical Mounting Tube with the screw hole in the Plastic Wall Spacer. Now, take 1 of the 2.5" inch long Wall Screws and put it through the bottom screw hole in the Vertical Mounting Tube which should be aligned with the hole in the Plastic Wall Spacer. If properly aligned, the Wall Screw should go all the way through and touch the wall. If not, re-align the holes.

4. Next, screw the Wall Screw into the wall but DO NOT fully tighten the screw at this point.

5. a.) Next, take the 2nd Plastic Wall Spacer and, from the top of the tube, slide it behind the Vertical Mounting Tube. Gently slide the Plastic Wall Spacer down until the screw hole aligns with the middle screw hole of the Vertical Mounting Tube. b.) Take another 2.5 inch long Wall Screw and put it through the middle hole and screw it into your wall. Again, DO NOT fully tighten the screw yet. Repeat this process with the 3rd Plastic Wall Spacer using the top hole. Once you have all 3 screws in the wall you can now tighten them down. Tighten the screws up so that the Vertical Mounting Tube is secure and can not move.

6. Repeat steps 1-5 if installing to another wall with Baseboard on the opposite side. If the opposite side is a wall with without a Baseboard, see page 3. If the opposite side is a Banister Post, see page 5.

7. Once the Vertical Mounting Tubes are securely mounted on both sides of the opening please see page 6.



Option B Mounting to Banister Post

5 of 7


Parts Needed:

- 1.) Part A: the Gate.
- 2.) Part D: Vertical Mounting Tube x2
- 3.) Part G: Top Round Banister Post Adapter x2
- 4.) Part I: Bottom Banister Post Adapter x2
- 5.) Part J: Bottom Corner Protectors x8
- 6.) Part K: 18" Velcro Straps attached with the buckle X 4




Installing the Gate:


- 1.) Slide the Top Round Banister Post Adapter on to the Banister Post.



- 2.) Place the Bottom Banister Post Adapter, I, and Bottom Corner Protectors, J, in Position as shown.



- 3.) Next, place the Vertical Mount Tubes, D, into the slots of parts, G, and I.




Part F is a built in Bubble Level, adjust the Vertical Mounting Tube so the bubble is in the middle of the circle.

- 4.) Secure the Velcro Straps around the Top and Bottom Banister Adapters.
See sequence 1 - 5 below.


You will need Velcro Straps attached with the buckle, K, and the Locking Tab, N.
(Note: Locking Tabs are only used at the top of the Banister Posts).




Step 1: Thread Velcro strap around banister post and through the buckle side of the strap.
(image step 1)



Step 2: Pull the strap so that it is tight and fold it over to connect the hook side of the strap to the loop side.



Step 3: Once correctly positioned, Pull Velcro Strap tight around Banister Post.
Next, Lock in place by closing the Locking Tab.




Step 4: Using the hex key provided in the hardware kit, insert the key into the screw and rotate it clockwise until the screw is snug. This will tighten up the strap so that the gate is secured to the banister post.

WARNING: Do not over tighten the screw or you may end up stripping out the screw head!

Step 5: Repeat steps 1- 4 for other banister post mounts.

Note: The buckle can be rotated to any point around the banister post so that it is out of sight.



Step 6: Once the Vertical Mounting Tubes are securely mounted on both sides of the opening, please see page 6 for further installation instructions.



Attaching Your Gate

7 of 7

1.) **Note: This applies to all installation types.** With the Vertical Mounting Tubes securely attached to each Banister Post or wall, simply slide the End Pins, C, through the hinge holes. Attach the swing side of the gate first by placing the top and bottom End Pins, C, through the top and bottom hinge holes bracket of the Vertical Mounting Tube, D. If you want to reverse your gate simply pinch the tabs on part C and guide it out of the hinge bracket holes and flip the gate around.



Press the tabs in while lifting up to simply

2.) Operating the Gate. **Note: Applies to all installation types.**

To Close Your Gate:



1. Slide the gate to the closed position.

2. With the gate spanning the opening, lift up on the gate so the End Pins, C, line up with the holes in the Vertical Mounting Tube, D, and drop in. See sequence 1-4 on right hand side for example.



To open:



To Open your gate simply Squeeze the latch lift up and slide the gate back Tip: For easier opening use your other hand to lift up in the middle of the gate while opening.

3.) **Note: This applies to all install types.** With your Gate locked in the opening, adjust the stabilizing Foot, H, by turning it clockwise until it just touches the floor.
Note: If you adjust the foot too far your gate will not lock properly when used in the future. After the foot has been adjusted, next turn the Locking Wheel counter clockwise until it's tight against the Foot.



Carlson
Pet Products

Carlson Pet Products, Inc
14305 Southcross Drive, Suite 105,
Burnsville, MN 55306
Phone: 952-435-1084

11/10/2010-V1